



P.O. Drawer 349, Monticello, GA. 31064

Order: 800-542-7659

Phone: 706-468-2801

Fax: 706-468-2881

E-Mail: polytech@polyskid.com

End Skid Kit for John Deere 200 Series Flex Head:

This supplemental kit is design for use with your Poly Last™ combine skid kits.

BE SURE THIS KIT CONTAINS THE FOLLOWING BEFORE YOU BEGIN INSTALLATION.

One pair Poly Last 200 Series end skids / Two special duty drill bits.

INSTALLING YOUR POLY LAST™ COMBINE SKIDS ON A 200 SERIES HEAD

1. The Poly Last™ poly skid kit you purchased was designed to fit both 200 & 900 Series flex heads. Because of this there will be a few differences in the poly panels and your 200 series steel panels. Do not be alarmed. This is common and in no way compromises the performance of the product.
2. The 200 Series end skids in this kit replace the 900 Series end skids included in your poly skid kit.
3. The instruction sheet included in your poly skid kit should be used for installation. This supplemental kit is designed to explain the differences in your 200 series panels and insure a trouble free installation.
4. Two special drill bits have been included in this package for drilling your steel panels. It is very important that the center holes in the poly panel be used in this installation.
Failure to do so will compromise the performance of the product.
5. The left end skid on the earliest models of 200 series grain heads is very narrow. If your head uses this end skid the poly will be wider than the steel. The poly may be installed as is and will function properly. Should you be uncomfortable with the wide poly you can mark it and cut to size.
6. The original left end panel of the 200 series grain head varies slightly from the 900 series. The poly panel will not be an exact match on this panel. (SEE BELOW) This is normal and does not effect the performance of the product.

NOTE: If your original steel has been replaced with more recent steel the poly will match the new steel.



The remainder of your Poly Last panels should match your steel 200 series panels.
If you have any questions or concerns please call Poly Tech at 1-800-542-7659 for assistance.